

Using the Water+ Truck Fill System



This is the Man Machine Interface at the Access Terminal. Your customers use this to enter their information prior to receiving water.

CUSTOMER OPERATION SEQUENCE

1. Connect truck hose to station camlock outlet if using the lower fill line or ensure you are under the upper fill line. For stations with more than one hose you will be prompted to select a hose.
2. Select **Upper** if you wish to fill at the top of the truck and select **Lower** if you wish to use the fill line from the side of the building.
3. Input your **Access Number** that was obtained from the town. If incorrect press **CLR** to clear last digit or **RESET** to start over. When correct press **Enter**.
4. Input **PIN** number.
5. Enter desired **Volume**. Press **Enter** key. ****NOTE**** Volume is in cubic meters. Example: If you want 1000 litres, enter 1.00 then press enter. If you want 500 litres enter 0.50 then press enter.
6. The message **??Hose Connected??** appears.
7. Press **START**. Discharge stops when entered volume of water has been discharged.
8. Note: To stop water before discharge is complete press **STOP**. Customer will be charged for volume of water dispensed not volume selected.
9. Unhook hose from fill line.